

PRINT ON STD LETTER SIZE IN LANDSCAPE ORIENTATION AT 100% SCALE

NOTES: TEST THE FIT ON BOTH SIDES OF THE CALIPER. DUE TO THE TAPER OF THE WHEEL THE OUTER SIDE IS MORE LIKELY TO HAVE INTERFERENCE. DIRECTIONS: COPY OR PRINT ONTO CARD STOCK. MEASURE INDICATED DIMENSIONS AFTER PRINTING TO MAKE SURE SCALE IS 1 TO 1. CUT ALONG DARK LINES - FOLD TABS ALONG DOTTED LINES TO SIMULATE HEATSINK HEIGHT. INSTALL BETWEEN BRAKE PAD AND CALIPER PISTON WITH PRINTED SIDE TOWARDS CALIPER PISTON. RE-INSTALL WHEEL AND CHECK CLEARANCE - MUST HAVE AT LEAST 3/32" CLEARANCE AT ALL POINTS.

MAKE SURE WHEEL BALANCING WEIGHTS WILL NOT HIT THE COOLSHIM WHEN INSTALLED! REMOVE CUT-OUTS BEFORE DRIVING!